



Box Contents:

- X1 Domed M8 nut - MS BZP
- X1 Socket head cap screw M8 X70mm BZP
- X3 DIN 125 nylon washer 8.4 x 16x1.6mm
- X1 65mm open clamp handle M8 X 15mm
- X4 3 x 25 PAN POZI screws
- X4 M3 x 9 x 0.8mm washers

Assembly instructions:

1. Remove items from boxes.
2. Remove stainless steel tube from the DJC-STS3000B.
3. Secure stainless steel tube to DJC-STS3000P using M8 socket head cap screw, 2 nylon washers and M8 dome nut.
4. Fit nylon washers between stainless tube and plate bracket before fitting clamp handle to tube.
5. M8 screw assembly to be finger tight
6. Refit plate 2 complete with tube back in to DJC-STS3000B

CDJ-3000 fitting instructions :

- Position unit over location standoffs
- Secure unit by fixing with 4 screws and washers

Assembly instructions:

